

# LED-3010 INSTRUCTION



1. Remove front nose from hood.



2. Remove the oem light assembly



3. Cleaning the front nose



4. Mark under the hole according to LED-3010 frame. Cut out the nose housing using the marks. Do not damage the bolt thread.



5. Check the installation of LED-3010 frame, it may take several times to align properly.



6. Check to make sure the slots on the tab are aligned with nose. And we may need to bend the tab a little.



7. Install the frame, and bolt the tab, then mark the place for glue on nose.



8. Polish the marked area on nose until it's white, and clean the surface, it should be no paint, dry and free of oil.



9. Mix the glue and spread thin layer at the marked area, install the tab according to slot on frame within 3~4 mins. And let's sit for 8~10 mins.



10. After 8~10 minutes, remove LED-3010 frame, and reinstall nose to hood without frame. Once nose is installed on hood reinstall frame.



11. Install the LED lights in same direction to assure the wiring tabs are all facing the same way, mount front bezels using screws to hold lights in place, and tighten screws equally.

12. Connect wiring harness, red wire to positive, black wire to negative.